

Installation Instructions for the Bellview Rocker Theater Chairs

STEP 1:

Mount your leg standards on a 22-½ inch center to center layout to your floor.

Helpful Note:

If mounting to wood we suggest using 3/8 by 1-½ inch lag bolt.

If mounting to concrete there are many different concrete anchors you can pick up at any local hardware store.



Once you have mounted your leg standards to your floor you will want to attach your back on next.

Helpful Note:

You may want to leave your leg standard hardware a little loose until back and seat are attached.



Close up picture of the back bracket



Close up picture of the leg standard rocker mount

Installation Instructions for the Bellview Rocker Theater Chairs

STEP 2:

Place the back bracket over the leg standard rocker mount. The metal studs will line up with back bracket holes. Attach nut hardware provided as shown below.



STEP 3:

Using a 12mm socket or wrench, tighten down the nuts to the metal studs on the leg standard rocker mount as shown below.



Installation Instructions for the Bellview Rocker Theater Chairs

You are now ready to mount your seat.



Close up picture of the seat spring



Close up picture of the leg standard seat slot

STEP 4(A):

The seats have loaded springs which you will need a 7/16 open wrench to wind back before installing into the leg standard slot.



STEP 4(B):

With the seat in position. Take your wrench and wind the spring towards the back of the chair on each side until it will drop into place.



Installation Instructions for the Bellview Rocker Theater Chairs

This is what the completed chair will look like.



If you need assistance with assembly or installation please call our sales office.
We are available Monday – Friday 9 AM to 5 PM EST.

www.SeatsandChairs.com

Toll-Free: 1-800-632-7657

Office: 727-393-0400

Fax: 727-393-9600

Email: info@seatsandchairs.com